



oil in

oil out

gear oil change -
rear left side on the
bottom.