



Place the bike on the center stand (not the side stand)

This is done to make sure that the bike will not get away from you when initially started.

LANCE
POWER SPORTS.COM



Make sure to turn the key switch clockwise to the "ON" position.

LANCE
POWER SPORTS.COM




Turn the Safety Shut-off Switch to the "Run" position. The Safety Shut-off Switch is located on the left handle bar; it is the little red push button. Make sure that this button is "out" or the engine will not start.

LANCE
POWER SPORTS.COM



Grab either brake lever.
(Using the left brake lever is easier so that you are able to turn the throttle when starting)

LANCE
POWER SPORTS.COM



If the carburetor has not been primed, then it may take a few minutes to deliver gasoline to the engine. To avoid draining the battery, use the kick-starter 10-20 times.

LANCE
POWER SPORTS.COM



Once the kick-starter has been used to 10-20 times the bike should start. If it has not started yet, use the Starter Button on the right handlebar.

Do not hold the starter button for more than 5-10 seconds at a time. Every time it is pressed, give it an additional 5 seconds before pressing it again.

LANCE
POWER SPORTS.COM



Let the bike warm up for 5 to 10 minutes before riding. This will ensure the longevity of the engine. If you have any problems with starting the bike, please refer to our Troubleshooting Page.

LANCE
POWER SPORTS.COM